
Müslim Yılmaz – 150119566

- Modulation frequency 1: 20kHz Massage 1: follow, ideal
- Modulation frequency 2: **28kHz** Massage 2: **independent, look**


Demodulating of Massage 1 - 20kHz -

• Composite signals in frequency domain



• Bandpass Filter for Massage 1


Bandpass filter to filter out 1st recording from the composite signal



Bandpass filter is in the range [- 20000 -3 kHz, -20000 + kHz],[
 20000- 3kHz, 20000+3 kHz]

 $filter = ((frequencies < sf+fd) \& (frequencies > sf-fd)) \mid ((frequencies > -sf-fd) \& (frequencies < -sf+fd))$


• Demodulation Stage 1



- Filtered result after the bandpass filtering.

filtered = np.multiply(filter, myrecording_in_frequency_modulated)

Demodulation Stage 2




- We get rid of the sidelobes after the convolution.

```
cos_x = np.cos(2 * np.pi * 28000 * time)
cos_x_ft = (fftshift(fft(cos_x)))
convolved = (1 / (2*np.pi) ) * (np.convolve(cos_x_ft, filtered, 'same'))
```

2 * np.pi * 20000 * time


• Lowpass frequency design



- We design new lowpass filter to get 0 around signals.

```
lowpass_filter = ((frequencies > -fd) & (frequencies < fd))</pre>
```


Demodulation Stage 3



After the multiplication in frequency domain we get around 0 signals.

filtered_convolved = np.multiply(convolved, lowpass_filter)

• Recoverd first recording in time domain




- After the inverse fr transform we get the signal.

filtered_convolved_in_time = ifft(ifftshift(filtered_convolved))


Demodulating of Massage 2 - 28kHz -

• Composite signals in frequency domain




• Bandpass Filter for Massage 2


Bandpass filter to filter out 1st recording from the composite signal




• Demodulation Stage 1



• Lowpass frequency design



Demodulation Stage 3



• Recoverd first recording in time domain

